

# FOAM-LOK™

## SPRAY FOAM INSULATION

## ENERGY SAVINGS FOR LIFE

# Foam-LOK FL2000

### Closed Cell Spray Insulation ICC ESR-2629

### Product Design

Foam-LOK™ is a **Closed-Cell** spray applied foam, which was developed using an EPA approved next generation blowing agent which when installed following application guidelines adheres tenaciously to framing members and substrates. Foam-LOK **Closed-Cell** spray foam provides superior energy economy and durability while significantly reducing unmanaged moisture and air infiltration.

### Product Use

As a component of a “systems approach” to proper building envelope construction, Foam-LOK **Closed-Cell** spray foam provides exceptional performance in minimizing heat transfer, moisture gain, air leakage, and improving racking strength.

### Recommended Product Applications

- Walls
- Floors
- Unvented Crawl Spaces
- Concrete Slabs
- Cold Storage
- Unvented Attics
- Vented Attics
- Vented Crawl Spaces
- Ducts
- Freezers
- Ceilings
- Piping
- Foundations
- Tanks
- Coolers

### Recommended Processing Parameters

Processing Designation	Regular
Winter	20-50°F
Regular	50-80°F
Summer	80°F- and above

Optimum hose pressure and temperature may vary as a function of the type of equipment, ambient and substrate conditions, and the specific application. It is the responsibility of the applicator to properly interpret equipment technical literature, particularly information that relates acceptable combinations of gun chamber size, proportioner output, and material pressures.

Processing Designation	Foam-LOK
Equipment Dynamic Pressure	1,000 - 1,400 psi
Preheat Temperature	125 - 135° F (52 - 57° C)
Hose Heat Temperature	125 - 135° F (52 - 57° C)
Drum Storage Temperature	65 - 85° F (18 - 30° C)

**Material shelf life: 6 months when stored within recommended temperature range.**

- 2:1 transfer pumps are recommended for material transfer from container to the proportioner.

- **CAUTION:** Extreme care must be taken when removing and reinstalling drum transfer pumps so as NOT to reverse the “A” and “B” components.

- Do not circulate or mix other suppliers’ “A” or “B” component into Foam-LOK containers.

### Physical Properties

Properties	Test Method/ Requirements	Value
Aged “R” Value:	ASTM C-518	6.3 per inch
Compressive Strength:	ASTM D-1621	25-30 psi
Core Density:	ASTM D-1622	2.0-2.3 lbs./ft3
Air Leakage:	ASTM E-283-04	< 0.02L/s/M2 at 2.0 inches
Closed Cell Content:	ASTM D-2856	> 90%
Tensile Strength:	ASTM D-1623	40-48 psi
Water Vapor Transmission @ 74°F, perm inch	ASTM E-96 2.5 max	1.98 perms @ 1”
Dimensional Stability: 28 days at 160°F, 100%RH	ASTM D-2126 15% max by volume change	4%
Sound Transmission:	ASTM E-413-2004 ASTM E-1332-90 ASTM C-423-02a	Sound Transmission Class 38 Indoor-Outdoor Transmission Class 28 Noise Reduction Coefficient 0.10

### Credentials/Certifications

- ICC ESR-2629

Foam-LOK is a **Class I** formulation, as Tested per ASTM E 84, and and at a thickness of 4.0 inches possesses the flammability characteristics shown below:

ASTM Method E 84	Class I
Flame Spread	≤25
Smoke Development	≤450

*Diversified Testing Modified NFPA 286 PER AC 377 Appendix X	
Location	SPF Thickness *
Wall Cavities	10 1/2 (266mm)
Ceiling Cavities in Attics and Crawl Spaces	11 1/2 (292mm)

- No Ignition Barrier Required



### Room Corner Fire Testing \*

With 1/2" Thermal Barrier (Sheetrock)

*NFPA 286	
Location	SPF Thickness *
Wall Cavities	Up to 12 in (305mm)
Ceiling Cavities	Up to 12 in (305mm)

**\*THESE VALUES REFER TO THE TOTAL THICKNESS OF THE PRODUCT TESTED, NOT THE MAXIMUM THICKNESS ALLOWED PER PASS OR APPLICATION. THIS FOAM MUST NOT BE APPLIED IN EXCESS OF 2.0 INCHES PER APPLICATION. THE FOAM SHOULD BE ALLOWED TO COOL FOR 20 TO 30 MINUTES OR UNTIL THE SURFACE TEMPERATURE HAS RETURNED TO AMBIENT BEFORE ADDITIONAL APPLICATIONS OF FOAM ARE ATTEMPTED. FOAM APPLIED IN EXCESS OF 2.0 INCHES OR WITHOUT ALLOWING FOR COOLING MAY RESULT IN, BUT IS NOT LIMITED TO EXCESS HEAT BUILD-UP AND RESULT IN FIRE OR THE GENERATION OF OFFENSIVE ODORS THAT MAY NOT DISSIPATE WITH TIME.**

### Thermal Barrier

IRC and IBC codes require that SPF be separated from the interior of a building by an approved fifteen (15) minute thermal barrier, such as 1/2" gypsum wall board or equivalent, installed per manufacturer's instructions and corresponding code requirements. There are exceptions to the thermal barrier requirement: (1) Code authorities may approve coverings based on fire tests specific to the SPF application. For example, covering systems that successfully pass large scale tests may be approved by code authorities in lieu of a thermal barrier; (2) SPF protected by 1" thick masonry does not need a thermal barrier. Certain materials that offer protection from ignition, called "ignition barriers," may not be considered as thermal barrier alternatives unless they comply with NFPA 286 or other full-scale burn tests. Applicators should request test data and code body approvals or other written indications of acceptability under the code to be sure that the product selected offers code-compliant protection.

### Vapor Retarder

Foam-LOK CC qualifies as a vapor retarder as defined by the International Code Council and ASHRAE (Class II) at a minimum thickness of 2 inches. Building construction types with a persistent, high moisture drive require additional moisture remediation, as local building codes dictate. This is including climate zones 5 and higher in the U.S., as defined in 2004 Supplement to the IRC, Table N1101.2.

### Handling and Safety

Respiratory protection is **MANDATORY!** Lapolla requires that supplied air and a full face mask be used during the application of any spray applied foam system. Contact Lapolla Industries for a copy of the Model Respiratory Protection Program developed by API or visit their website at [www.polyurethane.org](http://www.polyurethane.org). Persons with known respiratory allergies should avoid exposure to the "A" component. The "A" component contains reactive isocyanate groups while the "B" component contains amine and/or catalysts with blowing agents. Both materials must be handled and used with adequate ventilation. The vapors must not exceed the TLV (0.02 parts per million) for isocyanates. Avoid breathing vapors. Wear a NIOSH approved respirator. If inhalation of vapors occur, remove victim from contaminated area and administer oxygen if breathing is difficult. Call a physician immediately. Avoid contact with skin, eyes, and clothing. Open containers carefully, allowing any pressure to be relieved slowly and safely. Wear chemical safety goggles and rubber gloves when handling or working with these materials. In case of eye contact, immediately flush with large amounts of water for at least fifteen minutes. Consult a physician immediately. In case of skin contact, wash area with soap and water. Wash clothes before reuse.

Positive pressure ventilation of the work area is required to minimize the accumulation of vapors in the work area during the application. Improper application techniques of this foam system must be avoided. This includes excessive thickness, off ratio material, and spraying into rising foam. The potential results of improperly applied materials may include but is not limited to, excessive heat build-up, and may result in a fire or offensive odors which may not dissipate with time and/or poor product performance due to improper density of the applied material. Large masses of sprayed materials should be avoided. When large masses are generated they should be removed from the area, cut into small pieces and allowed to cool before disposal. Failure to follow this recommendation may result in a fire. It is recommended that a fire extinguisher be located in an easily accessible portion of the work area.

Applicators should ensure the safety of the jobsite and construction personnel by posting appropriate signs warning that all "hot work" such as welding, soldering, and cutting with torches should take place no less than 35 feet from any exposed foam. If "hot work" must be performed all spray polyurethane foam should be covered with an appropriate fire or welder's blanket, and a fire watch should be provided.

### In Case of Spills or Leaks Steps To Be Taken-

- Utilize appropriate personal protective equipment (PPE.)
- Contain and cover spilled material with a loose, absorbent material such as oil-dry, vermiculite, sawdust or Fuller's earth.
- Shovel absorbent waste material into proper waste containers
- Wash the contaminated areas thoroughly with hot, soapy water.
- Ventilate area to remove vapors.
- Report sizeable spills to proper environmental agencies.

### In Case of Fire

**Extinguishing Media-**Dry chemical extinguishers such as mono ammonium phosphate, potassium sulfate, and potassium chloride. Additionally, carbon dioxide, high expansion (proteinic) chemical foam, or water spray for large fires.

### DISCLAIMER

The data presented herein is not intended for use by nonprofessional applicators, or those persons who do not purchase or utilize this product in the normal course of their business. The potential user must perform any pertinent tests in order to determine the product's performance and suitability in the intended application, since final determination of fitness of the product for any particular use is the responsibility of the buyer.

All guarantees and warranties as to products supplied by Lapolla Industries shall have only those guarantees and warranties expressed in writing by the manufacturer. The buyer's sole remedy as to any material claims will be against the applicator of the product. The aforementioned data on this product is to be used as a guide and is subject to change without notice. The information herein is believed to be reliable, but unknown risks may be present. **NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING PATENT WARRANTIES OR WARRANTIES OF MERCHANTABILITY OR FITNESS FOR USE, ARE MADE BY LAPOLLA WITH RESPECT TO OUR PRODUCTS OR INFORMATION SET FORTH HEREIN.**